




EXTERIOR CONCEALED FASTENER (CF) SYSTEM OVERVIEW








Support Points Per Panel

- Minimum of 3 supports, vertically and horizontally are required except for planks under 20"
- Distance between the edge mounting points and the panel edges must be 1-2"
- The actual number of fastening points and distance between supports must be verified by a building professional for wind load as per load building code



Concealed Fastener Products



